

Add contractor logo here

Add supplier logo here



Support:
Distributor Phone # **Insert Info**
Contractor Phone # **Insert Info**
Verasys Tech Support (866) 663-6105
be-verasyssupport@jci.com

Warranty: 3 Year Limited Warranty
<https://www.johnsoncontrols.com/-/media/jci/be/united-states/legal/warranty/files/jci-3y-warranty-final-11202018.pdf?la=en&hash=DD21C45A73770C636ED6088662E78EB0ACD02FC9>

Drawings:	
1	Cover
2	Bill of Material
3	Riser
4	VZC Detail
5	VEC Detail
6	ZEC310 Detail
7	BYP200 Detail
8	SBH Detail
9	SBH Quick Start
10	SBH Internet
11	SBH Alerts & Alarms
12	Sensor Detail
13	Damper Detail
14	Address Detail
15	Power Supply Detail
16	Enclosure Detail
17	Standard Installation
18	Layout
19	Appendix

Disclosure:

The following drawings & parts quote is our best interpretation of the parts needed based on the information given for this specific project. It is your (the contractor's) responsibility to verify that the parts quoted meet the requirements (ex. quantities needed, parts required) and specifications of the project being quoted. If additional or different parts are needed in order to complete the project or meet the specification; please reach out to the distributor listed on your quote to address the issues before using this quote to bid to your customer. **ADDITIONAL OR DIFFERENT PARTS MAY RESULT IN A PRICE DIFFERENCE.**

Drawing Title									
Cover									
	REFERENCE DRAWING	NO.	REVISION-LOCATION	ECN	DATE	BY			
	Sales Engineer	Project Manager	Application Engineer	By Steve Nichols	DATE 12-30-2021	BY	DATE		
Project Title				Branch Information		CONTRACT NUMBER			
3rd Party COBP	VERASYS™					DRAWING NUMBER			
						1			


Verasys Bill of Materials				
System	Function	JCI Part No	Description	Qty
Network	Smart Building Hub	LC-SBH200-0S	Verasys Smart Building Hub	1
Network	Communication Wire	CBL-22/3-FC-PVC	System/Zone Bus Cable 22-3C Shielded NonPlenum Wire	1
Network	Communication Wire	CBL-22/2P-SAPVC	Sensor Bus Cable 22-2P Shielded NonPlenum Wire	1
MZ- Zone Coordinator	Zone Coordinator	LC-VZC100-0	Verasys Zoning Coordinator for VAV and COBP applications	1
MZ- Zone Coordinator	Zone Power	PSH300A	480/277/240/120V to 24V XFR, 3 Circuits 100VA each (Power for 18 Boxes)	1
MZ- 3rd Party Units	3rd Party Controller	LC-VEC100-0	3rd Party RTU (VAV, COPB)	1
MZ- 3rd Party Units	Duct Sensors	TE-6311M-1	8" Duct Sensor Metal Enclosure, Nickel	2
MZ- 3rd Party Units	Outside Temp	TE-6313P-1	Outside Air Sensor, Nickel	1
MZ - COBP Zones	NS Sensor	NSB8BTN240-0	TEMP, DISPLAY, SETPOINT, WHITE, LOGO	14
MZ - COBP Zones	Controller	LC-ZEC310-0	Field Installed, Zone Damper Controller No Damper	14
MZ- Bypass Damper	Controller	LC-BYP200-0	Field Installed, Bypass Damper Controller No Damper	1
MZ- Bypass Damper	Static Pressure Sensor	DPT2640-005D	Low Differential Pressure Transducer 0-5 in WC, 0-5VDC	1
MZ- Bypass Damper	Static Pressure Probe	FTG18A-600R	Duct Static Pressure Probe (Need 1 Per Sensor)	1

Feature	System Features the VEC100 can cover
Up to 2 Stage Cooling	Yes
Up to 4 Stage Cooling	Yes
Modulating Cooling	Yes
Up to 2 Stage Heating	Yes
Up to 3 Stage Heating	No
Modulated Heating	Yes
Heat Pump	Yes
Economizer	Yes
Title 24 Economizer	No
Demand Ventilation Control	Yes
Dehumidification	No
Humidification	No
Variable Air Volume	Yes
Changeover Bypass (COBP)	Yes
VFD for COBP	Yes

* add a 16awg 2 conductor stranded wire 1k foot roll of wire to your estimate for power to the controllers



Drawing Title						
Bill Of Material						
REFERENCE DRAWING	NO.	REVISION-LOCATION	ECN	DATE	BY	
Sales Engineer	Project Manager	Application Engineer	By Steve Nichols	DATE 12-30-2021	BY	DATE
Project Title	VERASYS		Branch Information	CONTRACT NUMBER		
3rd Party COBP				DRAWING NUMBER		
				2		

System Riser



Additional Notes

- The system bus and zone bus trunk wiring is shown as a guide.
- The controllers on the system bus can be in a different order but you still must follow the rules for end of line (EOL).
 - The controllers for the zone bus must go to the appropriate zone coordinator but can in a different order but you still must follow the rules for end of line (EOL).





Drawing Title
Riser Detail

Project Title
3rd Party COBP

REFERENCE DRAWING	NO.	REVISION-LOCATION	ECN	DATE	BY
Sales Engineer	Project Manager	Application Engineer	Steve Nichols	DATE 12-30-2021	BY
Contract Information			CONTRACT NUMBER		
DRAWING NUMBER			3		

Verasys Zone Coordinator



USB PORT IS USED FOR
UPDATING FIRMWARE

Tech Tip: To upgrade firmware on the VZC download it from the verasyscontrols.com website. This firmware will also load new firmware on all the controllers connected to the Zone Bus. This update will take awhile depending on how many controllers are connected.

Tech Tip: If you change a dipswitch while the device is powered you will need to do a power cycle for the new address to show up.

Tech Tip: Get the VZC communicating with the SBH first. Then add a controller at a time. It can take a long time for devices to show up under the VZC. You may even need to do a power cycle on the VZC to force it to look for new controllers.

SEE RISER DRAWING FOR
SYSTEM BUS WIRING

SEE RISER SCHEDULE SET EOL TO ON IF
VZC100 IS THE END OF THE LINE ON THE
SYSTEM BUS

... See page 14 for more dipswitch addresses

EACH CONTROLLER NEEDS A UNIQUE ADDRESS. SEE RISER DRAWING FOR CONTROLLER ADDRESS

ON THE LAST DEVICE SET THE EOL
TO "ON"


SCHEDULING: THE ZONE COORDINATOR WILL HOLD A SCHEDULE FOR THE UNIT AND ASSOCIATED ZONES. WHEN THE SCHEDULE IS OCCUPIED THE UNIT AND ZONES ASSOCIATED TO THE COORDINATOR WILL BE INDEXED TO OCCUPIED. WHEN THIS SCHEDULE IS SET TO UNOCCUPIED THE UNIT AND THE ZONES WILL BE SET TO UNOCCUPIED.

SYSTEM TYPE: THRU THE INTERFACE IN ZONE COORDINATOR THE COORDINATOR CAN BE SET TO CONTROL A VAV SYSTEM OR A CHANGE OVER BYPASS SYSTEM DEPENDING UPON SELECTION THE UNIT AND ZONE WILL OPERATE AS FOLLOWS.



VAV SYSTEM: WHEN SET TO VAV, THE UNIT WILL CONTROL TO THE DISCHARGE AIR TEMPERATURE SETPOINT WHICH IS RESET BASED ON A REPRESENTATIVE ZONE. IF THIS FEATURE IS DISABLED THE UNIT WILL CONTROL TO A FIXED DISCHARGE AIR TEMPERATURE. IN ADDITION TO TEMPERATURE THE UNIT WILL CONTROL THE PRESSURE WHICH MAYBE RESET BASED ON THE DAMPER OF THE ZONE CALLING FOR THE MOST COOLING. IT TOO MAYBE DISABLED AND A FIXED SETPOINT CAN BE SET. THE VAV BOXES WILL CONTROL EACH ZONE TO THE ZONE SETPOINT USING THE UNITS COOLING FOR COOLING AND THE BOX HEAT FOR REHEAT (IF AVAILABLE).

CHANGE OVER BYPASS SYSTEM: WHEN SET TO CHANGE OVER BYPASS, THE UNIT WILL CONTROL THE DISCHARGE AIR TO PROVIDE EITHER HEATING OR COOLING DEPENDING UPON THE VOTE OF THE ZONES. THE USER WILL HAVE THE ABILITY TO DECLARE WHICH ZONE CAN VOTE AND HOW MUCH VOTING POWER THEY WILL HAVE. THE PRESSURE IN THE DUCT WILL BE CONTROLLED BY THE BYPASS DAMPER CONTROLLER. EACH ZONE DAMPER WILL INDEPENDANTLY CONTROL TO HEATING OR COOLING DEPENDING UPON THE DISCHARGE OF THE UNIT. IF THE ZONE IS CONTROLLED BY A VAV BOX THE ZONE MAYBE ABLE TO PROVIDE HEATING WHEN THE DISCHARGE IS COOLING. WHEN THE UNIT IS OFF THE BYPASS DAMPER WILL INDEX TO 50%.

THIS IS A SIMPLIFIED SEQUENCE FOR HOW THE VAV AND CHANGE OVER BYPASS SYSTEM WILL WORK. FOR MORE DETAILED INFORMATION SEE THE VERASYS USER MANUAL.

Drawing Title VZC Detail									
	REFERENCE DRAWING		NO.	REVISION-LOCATION			ECN	DATE	BY
	Sales Engineer	Project Manager	Application Engineer	BY Steve Nichols	DRAWN	DATE 12-30-2021	APPROVED		
Project Title 3rd Party COBP				Branch Information			CONTRACT NUMBER		
							DRAWING NUMBER 4		

VEC RTU Controller



SUPPLY FAN START/STOP: THE SUPPLY FAN WILL BE STARTED ACCORDING TO THE SCHEDULE AND THE CONTROL SEQUENCE WILL BE ENABLED. IF THE SUPPLY FAN STATUS DOES NOT MATCH THE COMMANDED VALUE AFTER AN ADJUSTABLE PERIOD OF TIME, AN ALARM WILL BE GENERATED THIS FEATURE CAN BE DISABLED. A TOTALIZATION ALARM CAN ALSO BE SETUP TO GENERATE AN ALARM AFTER THE FAN HAS REACHED THE RUN HOURS. THIS LIMIT CAN BE USED TO SET SERVICE ACTIVITIES LIKE FILTER REPLACEMENT. SETTING THE LIMIT TO 0 WILL DISABLE THIS ALARM.

STATIC PRESSURE CONTROL: THE BYPASS DAMPER WILL MODULATE TO MAINTAIN THE DISCHARGE STATIC PRESSURE AT SETPOINT. THE CONTROLLER FOR THIS IS A SEPARATE CONTROLLER.

DISCHARGE AIR TEMPERATURE CONTROL: THE MIXED AIR DAMPERS, ELECTRIC HEATING STAGES, AND THE DX COOLING STAGES WILL MODULATE/CYCLE TO MAINTAIN THE DISCHARGE AIR SETPOINT THAT IS ADJUSTED TO PROVIDE HOT OR COLD AIR DEPENDING UPON WHAT THE MAJORITY OF THE ZONES ARE CALLING FOR. IF THE CONTROLLER IS CALLING FOR COOLING AND THE DISCHARGE AIR DOES NOT DROP OVER AN ADJUSTABLE PERIOD OF TIME A COOLING ALARM WILL BE GENERATED. LIKEWISE IF A CALL FOR HEATING AND THE TEMPERATURE DOES NOT RISE OVER A PERIOD OF TIME A HEATING ALARM WILL BE GENERATED. AGAIN THESE ALARMS MAYBE TURNED OFF BY SETTING THE TIME PERIOD TO 0.

ECONOMIZER DRY BULB SWITCHOVER: WHEN THE OUTSIDE AIR TEMPERATURE IS BELOW THE SWITCHOVER SETPOINT, THE ECONOMIZER WILL BE ENABLED. WHEN THE OUTSIDE AIR TEMPERATURE RISES ABOVE THE SWITCHOVER SETPOINT PLUS A DIFFERENTIAL, THE ECONOMIZER WILL BE DISABLED. IF ENABLED, THE ECONOMIZER LOW LIMIT WILL MODULATE THE DAMPER CLOSED WHEN THE DISCHARGE AIR REACHES A LOW LIMIT SETPOINT. IF AT ANYTIME THE PURGE CONTACT IS INITIATED THE DAMPERS WILL BE POSITIONED WIDE OPEN.

DEMAND VENTILATION CONTROL: IF THE WHEN RETURN AIR CO2 SENSOR IS CONNECTED, THE MINIMUM OUTSIDE AIR DAMPER POSITION WILL BE PROPORTIONALLY INCREASED IF THE RETURN AIR CO2 RISES ABOVE SETPOINT UNTIL IT HITS THE MAXIMUM POSITION SETPOINT.

NIGHT SETBACK/NIGHT SETUP: WHEN IN “UNOCCUPIED” MODE, THE UNIT WILL CYCLE AS NECESSARY TO MAINTAIN THE SHARED NIGHT SETBACK ZONE TEMPERATURE AT SETPOINT. A DIFFERENTIAL PREVENTS THE UNIT FROM CYCLING EXCESSIVELY.

SHUTDOWN:


WHEN THE UNIT IS SHUTDOWN BY EITHER A STOP COMMAND OR SYSTEM SAFETY THE UNIT WILL BE SET AS FOLLOWS:

SUPPLY FAN WILL BE OFF
BYPASS DAMPER WILL BE COMMANDED TO 50%
OUTSIDE AIR DAMPER WILL CLOSE
RETURN AIR DAMPER WILL OPEN
DX COOLING WILL BE OFF
ELECTRIC REHEAT WILL BE OFF



You have 2 options when addressing a VEC zone controller:

1-From the display on the front of the VEC press **"ent"**, arrow down to **"Controller"** & press **"ent"**, arrow down to **"Network"** & press **"ent"**, arrow down to **"Address"** & press **"ent"**, press **"ent"** a 2nd time & the screen will blink, use the up or down arrow to change the address & press **"ent"**. **Note:** You may need to do this 2 times for the address to stick

2-Connect the VEC to the smart building hub & power up the VEC. Once the SBH recognizes the VEC click on “Controller”, “Network”, & change “Address”.

Drawing Title VEC Detail								
	REFERENCE DRAWING	NO.	REVISION-LOCATION			ECN	DATE	BY
	Sales Engineer	Project Manager	Application Engineer	DRAWN BY Steve Nichols			APPROVED DATE 12-30-2021	
Project Title 3rd Party COBP				Branch Information			CONTRACT NUMBER	
							DRAWING NUMBER 5	

ZEC310 Zone Damper Controller for COBP



OCCUPIED MODE: THE ZONE DAMPER CONTROLLER WILL MONITOR WHETHER WARM OR COOL AIR IS BEING SUPPLIED. ON A RISE IN ZONE TEMPERATURE ABOVE THE OCCUPIED COOLING SETPOINT AND SUPPLY AIR IS COOL, THE PRIMARY AIR DAMPER WILL MODULATE OPEN. ON A DROP IN ZONE TEMPERATURE BELOW THE OCCUPIED HEATING SETPOINT AND SUPPLY AIR IS WARM, THE PRIMARY AIR DAMPER WILL MODULATE OPEN. IF THE SUPPLY AIR IS NOT THE TYPE, WARM OR COOL, TO SATISFY THE COOLING OR HEATING REQUIREMENTS, THE PRIMARY AIR DAMPER WILL REMAIN AT MINIMUM POSITION.


UNOCCUPIED MODE: ALL ZONE DAMPER CONTROLLERS WILL BE INDEXED TO UNOCCUPIED HEATING AND COOLING SETPOINTS AND THE PRIMARY AIR DAMPERS FULLY OPEN. ON A RISE IN ZONE TEMPERATURE ABOVE THE UNOCCUPIED COOLING SETPOINT AND SUPPLY AIR IS COOL, THE PRIMARY AIR DAMPER WILL MODULATE OPEN. ON A DROP IN ZONE TEMPERATURE BELOW THE UNOCCUPIED HEATING SETPOINT AND SUPPLY AIR IS WARM, THE PRIMARY AIR DAMPER WILL MODULATE OPEN. IF THE SUPPLY AIR IS NOT THE TYPE, WARM OR COOL, TO SATISFY THE COOLING OR HEATING REQUIREMENTS, THE PRIMARY AIR DAMPER WILL REMAIN AT MINIMUM POSITION.


SUPPLEMENTAL HEATING (OPTIONAL): OUTPUTS FOR SUPPLEMENT HEATING WILL ALLOW THE USE TO ADD SUPPLEMENTAL HEATING TO THE CONTROLLER. IF ADDED AND SUPPLEMENTAL HEAT IS SET TO TRUE THE CONTROLLER WILL TRY TO USE SUPPLEMENTAL HEATING BEFORE VOTING FOR UNIT HEATING. IF THE SPACE DOES NOT SATISFY WITH ALL OF THE LOCAL HEAT THE CONTROLLER WILL VOTE FOR HEAT AND IF AVAILABLE WILL ALSO USE IT TO SATISFY THE SPACE.

BOX HEATING (OPTIONAL): OUTPUTS FOR BOX HEATING WILL ALLOW THE USE TO ADD BOX HEATING TO THE CONTROLLER. IF ADDED THE CONTROLLER WILL TRY TO USE BOX HEATING BEFORE VOTING FOR UNIT HEATING. IF SUPPLEMENTAL HEAT IS ALSO ADDED THE USER CAN DECIDE WHICH IS USED FIRST. IF THE SPACE DOES NOT SATISFY WITH ALL OF THE LOCAL HEAT THE CONTROLLER WILL VOTE FOR HEAT AND IF AVAILABLE WILL ALSO USE IT TO SATISFY THE SPACE.



OCCUPANCY LIGHTING SWITCH (OPTIONAL): A OCCUPANCY LIGHTING SWITCH CAN BE ADDED TO THE CONTROLLER AND WILL TEMPORARILY SET THE CONTROLLER TO STANDBY MODE WHEN THE OCCUPANCY IS NOT BEING SENSED. WHEN THE CONTROLLER SENSES OCCUPANCY, THE ZONE WILL SWITCH BACK TO OCCUPIED. STANDBY MODE USES STANDBY TEMPERATURE SETPOINTS THAT ARE SLIGHTLY HIGHER OR LOWER THAN THE OCCUPIED COOLING OR HEATING SETPOINTS RESPECTIVELY.

DEMAND CONTROL VENTILATION (OPTIONAL): WHEN THE ZONE CO2 SENSOR IS WIRED TO THE CONTROLLER, TO SENSE THE AIR QUALITY IN THE ZONE, THE MINIMUM DAMPER POSITIONS ARE PROPORTIONALLY RESET BASED ON AN AIR QUALITY (CO2) SETPOINT. THE RESET OF THE DAMPER MINIMUM POSITIONS DO NOT EXCEED THE MAXIMUM VALUE THAT THE USER SETS. IF THE CO2 SENSOR IS NOT CONNECTED THE CONTROLLER WILL USE THE COOLING MINIMUM POSITION AND THE HEATING MINIMUM POSITION.




Drawing Title ZEC310 Detail								
	REFERENCE DRAWING		NO.	REVISION-LOCATION		ECN	DATE	BY
	Sales Engineer	Project Manager	Application Engineer	DRAWN		APPROVED		
			By Steve Nichols	DATE 12-30-2021	BY	DATE		
Project Title 3rd Party COBP				Branch Information		CONTRACT NUMBER		
						DRAWING NUMBER 6		

BYP200 Bypass Damper Controller for COBP



OCCUPIED MODE: THE BYPASS DAMPER CONTROLLER WILL MONITOR THE DUCT STATIC PRESSURE. ON A RISE IN STATIC PRESSURE ABOVE SETPOINT, THE BYPASS DAMPER WILL OPEN TO DECREASE PRESSURE. ON A DROP IN STATIC PRESSURE BELOW SETPOINT, THE BYPASS DAMPER WILL MODULATE CLOSED TO INCREASE PRESSURE.






UNOCCUPIED MODE: WHEN THE SINGLE PACKAGED UNIT IS INDEXED OFF, THE BYPASS DAMPER WILL BE INDEXED TO 50%. IF THE SINGLE PACKAGED UNIT IS INDEXED ON, THE BYPASS DAMPER WILL CONTROL AS PER THE OCCUPIED MODE SEQUENCE.

Drawing Title BYP200 Detail											
	REFERENCE DRAWING		NO.	REVISION-LOCATION		ECN	DATE	BY			
	Sales Engineer	Project Manager	Application Engineer	DRAWN		APPROVED					
Project Title 3rd Party COBP				BY	Steve Nichols	DATE	12-30-2021	BY		DATE	
				Branch Information				CONTRACT NUMBER			
								DRAWING NUMBER 7			

Smart Building Hub Information


LED Name	Color	Normal	Descriptions/Other Conditions
Power	Blue or Purple	On steady	Off = No power On Purple = Power is supplied by primary voltage On Blue = OS booted and power is supplied by primary voltage
Fault	Red	Off	Off = No faults/normal operation On steady = Missing hardware, missing software, operating system has not yet been initialized, or reset is in progress Slow flicker then fast flicker = Reset button is being pressed Medium flicker (2 blinks per second) = Startup sequence Fast flicker (5 blinks per second) = Fault
Ethernet	Blue	Flicker with activity	Off = Receiving data On steady = Transmitting data Flicker = Data transmission
100/1G Link	Blue	On steady	Off = no network connection On steady = network is connected
Run	Blue	On steady	Off = No power or waiting for processes to start On steady = OS and all monitored processes have started and the device is ready to use
Upgrade	Blue	On steady	Off = No upgrade in progress On steady = upgrade in progress
USB A	Blue	On when a device is connected	Off = No device is connected On steady = a device is connected
USB B	Blue	On when a device is connected	Off = No device is connected On steady = A device is connected
System Bus	Blue	Flicker with activity	Off = Not receiving data On steady = Transmitting data Flicker = Data transmission
Wi-Fi AP	Yellow	Flicker with activity	Off = No Wi-Fi adapter connected On steady = A device is connected to the Wi-Fi Network of the SBH Flicker = Wifi adapter is connected but no devices are connected
EOL	Yellow	On if the device is the end of the line Off if it is in the middle of the bus	Off = EOL not switched on On steady = EOL is switched on
W-Fi Client	Yellow	Not Used	Not Used - This will be used at a future date

Reset Function	Reset Operation ¹
Reset the Wi-Fi and Ethernet Settings	<ol style="list-style-type: none"> 1. Press and hold the RESET button for two seconds. The FAULT LED displays slow flicker behavior. 2. Release the RESET button within three seconds. The FAULT LED continues slow flicker behavior. 3. Within five seconds, press the RESET button again, and then immediately release it to confirm that you want to reset Wi-Fi and Ethernet settings. If you do not press the reset button to confirm within five seconds, the reset operation is canceled. <p>Result: You have reset the Wi-Fi SSID and passphrase and Ethernet settings to factory defaults. The LEDs stop flickering for two seconds, then the LEDs return to normal operation, based on the current state of the device.</p>
Reset to Factory Defaults ²	<ol style="list-style-type: none"> 1. Press and hold the RESET button for six seconds. After two seconds, the FAULT LED displays slow flicker behavior. This changes to fast flicker behavior after an additional four seconds of holding the RESET button. 2. Release the RESET button within three seconds of seeing fast flicker behavior. The FAULT LED continues fast flicker behavior. 3. Within five seconds, press the RESET button again, and then immediately release it to confirm that you want to reset to factory defaults. If you do not press the RESET button to confirm within five seconds, the reset operation is canceled. <p>Result: You have reset all unit settings to factory defaults. The LEDs stop flashing for two seconds, then the LEDs return to normal operation, based on the current state of the device.</p>



- 1 Every SBH comes with a Quick Start Guide that gives you the login information
 - 2 When you first login into the SBH it will prompt you to change the default login **(SAVE THIS NEW LOGIN INFO)**
 - 3 If you forget or lose the login information follow the info above
 - 4 If you don't have the Quick Start Guide & need the default login use the following...

Verasys-SBH
SBH-XXXXXX(last 6 digits of your mac address on the back of the SBH)
Admin
SBH-XXXXXX(last 6 digits of your mac address on the back of the SBH)
 - 5 The Wi-Fi dongle can be used in either USB port
 - 6 The SBH can be powered by a 24vdc, 50w, Class II power supply or you can use a 24vac , 75va Class II transformer
 - 7 The SBH can be mounted on denrail or screwed down using the standoffs

Drawing Title SBH Detail							
	REFERENCE DRAWING		NO.	REVISION-LOCATION		ECN	DATE BY
	Sales Engineer	Project Manager	Application Engineer	DRAWN BY Steve Nichols		DATE 12-30-2021	APPROVED BY DATE
Project Title 3rd Party COBP				Branch Information		CONTRACT NUMBER	
						DRAWING NUMBER	
						8	


1. Connect the Smart Building Hub to Equipment

The Smart Building Hub (SBH) permanently connects to the Verasys™ system using the 4-terminal System bus port. Wire the system bus communications to the blue, 4-terminal connector and plug it into the port.

Note: If this device is at the end of a line, set the end of the line switch to on.


Note: The RJ-12 jack next to the 4-terminal block can be used as a temporary connection to the System bus using the RJ-12 cable supplied with the SBH.

Figure 1: Connecting the SBH



- Wire your cable to the supplied four-pin adapter as illustrated.
- Plug the Wi-Fi adapter that comes with the SBH into either of the USB ports.
- Connect the RJ45 Ethernet port to the building Ethernet network as instructed by the building IT department. The Ethernet must be plugged into the device if you choose the (optional) Ethernet setup in step 6.
- Connect power to the Smart Building Hub.
Once power is supplied to the SBH, the **WiFi AP** LED flashes to indicate that the device is initializing. When the **Fault** LED turns off, the **WiFi AP** LED flashes, and the **RUN** LED is on, you can connect the SBH using the built-in Wifi access point.

Figure 2: SBH LED Map



2. Connect to the Smart Building Hub Wi-Fi access point

The SBH can be configured over Wi-Fi using a mobile device or laptop.

- In your Wi-Fi enabled device, access the Wi-Fi settings and select the Verasys-SBH access point name.
- Connect to the SBH Wi-Fi network using the supplied credentials from the beginning of this guide.

3. Open a Web Browser

- Navigate to the following URL: www.smartbuildinghub.com, to open the SBH browser interface.

Note: The SBH ships with a private [smartbuildinghub.com](#) SSL certificate installed to ensure secure communication with the SBH. However, this certificate does not indicate that it is trusted in a browser. If you wish to install your own certificate, refer to the [Smart Building Hub Network and IT Guidance Technical Bulletin \(LIT-12012324\)](#) for more information.

4. Log in to the Smart Building Hub

- Use the default Admin login credentials from the beginning of this guide.
- Read and accept the SBH license agreement.

5. Change Passwords and SSID

The first time you log into the SBH, the **Change Password and Passphrase** web page appears. You must change the Admin password, Wi-Fi passphrase, and the SSID.

IMPORTANT: After you change the Wi-Fi passphrase or SSID, the web server restarts and you must rejoin the SBH Wi-Fi network using the new passphrase. On some mobile devices, you must select and forget the original SBH Wi-Fi network before rejoining the network with the new passphrase. A laptop running Microsoft Windows is a device that behaves this way.

- In the **New Admin Password** field, enter a new password.
- In the **Verify New Admin Password** field, enter the same new password.
- In the **New Wi-Fi SSID** field, enter the new Wi-Fi SSID.
- In the **New Wi-Fi Passphrase** field, enter the new Wi-Fi Passphrase.
- Click the **Save** button.

Navigate to the following URL: www.smartbuildinghub.com, to open the SBH browser interface.

Note: The SBH ships with a private smartbuildinghub.com SSL

certificate installed to ensure secure communication with the SBH. However, this certificate does not indicate that it is trusted in a browser. If you wish to install your own certificate, refer to the *Smart Building Hub Network and IT Guidance Technical Bulletin (LIT-12012324)* for more information.

Navigate to the following URL: www.smartbuildinghub.com, to open the SBH browser interface.

Note: The SBH ships with a private smartbuildinghub.com SSL certificate installed to ensure secure communication with the SBH. However, this certificate does not indicate that it is trusted in a browser. If you wish to install your own certificate, refer to the *Smart Building Hub Network and IT Guidance Technical Bulletin (LIT-12012324)* for more information.

6. Ethernet Setup (Optional)

This step describes how to access the SBH over an Ethernet network.

- In the SBH UI, navigate to **Settings > Ethernet**.
- On the **Ethernet** drop-down list, select **On** to enable the SBH Ethernet port.
- Click the **Save** button.
- Take note of the address in the IP Address field. By default, the SBH is configured to dynamically receive an IP address from your network using DHCP.
Note: If the IP Address does not appear, refresh the screen.
- Enter the IP address from the previous step. You now have access to the SBH over an Ethernet network.
Refer to the *Smart Building Hub Network and IT Guidance Technical Bulletin (LIT-12012324)* for more options.

7. Use the Smart Building Hub


Select a device from the equipment list and use the web pages from the SBH to view, commission, and configure devices as needed.

IMPORTANT: Save this guide. It contains your default user name and password information. This information may be needed to reset your Smart Building Hub to factory defaults.

Technical Specifications

Smart Building Hub

Power Consumption	38W maximum
Ambient Temperature Conditions	Operating: 0 to 50°C (32 to 122°F) Operating Survival: -30 to 60°C (-22 to 140°F) Non-Operating: -40 to 70°C (-40 to 158°F)
Ambient Humidity Conditions	Storage: 5 to 95% RH 30°C (86°F) maximum dew point conditions Operating: 10-90% RH, 30°C (86°F) maximum dew point conditions

Drawing Title SBH Setup								
	REFERENCE DRAWING		NO.	REVISION-LOCATION		ECN	DATE	BY
	Sales Engineer	Project Manager	Application Engineer	DRAWN BY Steve Nichols DATE 12-30-2021		APPROVED DATE		
Project Title 3rd Party COBP				Branch Information		CONTRACT NUMBER		
						DRAWING NUMBER		
						9		

Choose a device...

Menu

Settings

Wi-Fi Access Point

Backup

Restore

Profiles

Clone

Ethernet

Load Shedding

Global Shutdown

System Settings

Verasys Enterprise

BACnet Settings

BBMD

SSL

Alarm Notifications

Software Updates

Administration

Custom Logo

SETTINGSETHERNET

Ethernet

3On

Hostname

SBH00108D0A7F56

Domain Name Suffix

Ethernet Mac Address

00:10:8d:0a:7f:56

Auto DHCP

4Off

IP Address

5Get From I.T. Group

Subnet Mask

6Get From I.T. Group

Default Gateway

7Get From I.T. Group

Auto DNS

Off

Primary DNS Server

88.8.8.8

Secondary DNS Server

98.8.4.4

Enable Proxy

No

Note: Smart Building Hub must be connected to an external power source for Ethernet to function.

Cancel10Save

Setting up Internet Access:

- Reach out to the customers I.T. group & get the following... a "Static IP Address", "Subnet Mask", "Default Gateway", & "Primary & a Secondary DNS Server"
- Log into the SBH, click on "Settings" then "Ethernet" & change "Auto DHCP" to "Off"
- Add the info you got from the IT group into the SBH & make sure there's a network cable plugged into the SBH & the customers internet.
- Turn off your wifi. Open Chrome or Safari & type in the ip address. This should bring you to the Verasys login page...if not you may need to log into the customers VPN. (Call customer I.T. people up for VPN access) & repeat Step 4.

Get This Info From Customer I.T. Group or I.S.P.
Then Write Info Here:

Static IP Address:_____

Subnet Mask:_____

Default Gateway:_____

Primary DNS Server:_____

Secondary DNS Server:_____

Email Host:_____

Email Port:_____

Mail Server User Name:_____

Mail Server Password:_____

VPN Address:_____

VPN User:_____

VPN Password:_____

After you set up the SBH
write down login info here

SSID:_____

Wi-Fi Password:_____

User Name:_____

User Password:_____

Drawing Title SBH Internet Info																
Project Title 3rd Party COBP	REFERENCE DRAWING			NO.		REVISION-LOCATION			ECN		DATE		BY			
	Sales Engineer		Project Manager		Application Engineer		DRAWN			APPROVED						
							BY Steve Nichols			DATE 7-6-2022			BY		DATE	
							Branch Information			CONTRACT NUMBER						
										DRAWING NUMBER			10			

Smart Building Alerts & Email Settings

Global Shutdown

System Settings

Verasys Enterprise

BACnet Settings

BBMD

SSL

1 Alarm Notifications


Software Updates


13 Administration

Custom Logo

Audit Log

Diagnostics





©2021 Johnson Controls International Plc.
All rights reserved. [Legal](#)
Patents: <https://jciapat.com>
SW Version: 4.1.0.37
OS Version: 20181004182348
Dictionary Version: 8.0.0.3797

ORE Up

SOCKET Up

SETTINGS

ALARM NOTIFICATIONS

Enabled

2 On

Use SSL/TLS

3 Yes

Host

Ex: mail.server.com

4 mail.server.com

Port

5 80

Locale

Notification emails will be sent using this locale

6 English

From Email Address

Notification emails will come from this address

7 This can be any email address

Site Name

8 Best to make this the name of the building

Username

9

☐ Set Password

Cancel

10 Save

Test Email Address

Address to send test email to

11 Enter the name of your email to verify it works

12 Send Test Email

Note: To get text & email alerts you need to be connected to the internet & set up a user for each person who needs to get alerts. Follow Steps 1-23

Setting Up Text & Email Alerts:
-Reach out to the customers I.T. group & get the following... a mail server "Host", "Port #"

Setting Up Text & Email Alerts:
-Reach out to the customers I.T. group & get the following... Mail Server "User Name" & "Password"

Adding Text Alerts:

AT&T [phone#nodashes@txt.att.net](#)
Verizon [phone#nodashes@vtext.com](#)
T-Mobile [phone#nodashes@tmomail.net](#)
Sprint [phone#nodashes@messaging.sprintpcs.com](#)
Cricket [phone#nodashes@mms.cricketwireless.net](#)
Virgin [phone#nodashes@vmobl.com](#)
Tracfone [phone#nodashes@mmst5.tracfone.com](#)
Metro PCS [phone#nodashes@mymetropcs.com](#)
Boost [phone#nodashes@myboostmobile.com](#)

If your cell carrier is not displayed go to Google & search for their text address

14 Add New User

ADMINISTRATION

ADD USER

Name

15 Brad Pitt

Username

No spaces

16 Brad

Password

Must contain 8 or more characters, 1 lowercase letter, 1 uppercase letter, 1 number

17

Verify Password

18

Role

19 Admin

Alarm Notification Level

20 Service Priority

Email Address 1


21 bradley.pitt@hollywood.com

Email Address 2

22 8038675309@txt.att.net

Cancel

23 Save

Drawing Title							
Alert & Email Setup							
Project Title		3rd Party COBP				DRAWING NUMBER	
						11	

REFERENCE DRAWING		NO.	REVISION-LOCATION		ECN	DATE	BY
Sales Engineer	Project Manager	Application Engineer	Steve Nichols	DATE	12-30-2021	BY	DATE
Contract Number		Branch Information		CONTRACT NUMBER			

NS8000 Zone Sensor Information

MAX

122°F

50°C

MIN

32°F

0°C

MAX 90% RH

MIN 10% RH

85°F (29°C) MAX DP

48 in (1.2 m)

Note:

- Locate the network sensor away from steam or water pipes, warm air stacks, unconditioned areas (not heated or cooled), or sources of electrical interference.
- Height requirements may vary depending on the site.
- Network sensors without CO₂ sensing are shock and vibration resistant, but not shock and vibration proof. Be careful not to drop the unit or mount it where it could be exposed to excessive vibration. Dropping a CO₂ network sensor may result in readings outside of the specified accuracy tolerance.

Icon	Description
1	Humidity indicator icon
2	Humidity measurement
3	CO ₂ measurement
4	Configurable setpoint or current temperature
5	Setpoint indicator icon
6	Fahrenheit icon
7	Celsius icon
8	Percent relative humidity icon
9	Fan speed bars
10	Fan icon
11	Automatic fan speed icon
12	Up adjustment or navigation icon
13	SA bus online indicator
14	Down adjustment or navigation icon
15	Menu or enter icon
16	Occupancy indicator
17	Default display value (setpoint, zone temperature, relative humidity)





























- To change the display from °C to °F hold down
- Once you connect the NS to a controller that is connected to a SBH it will hold it's parameters when there's a power cycle
- The NS8000 uses a dipswitch to address it
- If the sensor is the only one on the bus there is no need to change the default address of 199
- You can have a max of 8 NS sensors on the sensor bus that can be daisy chained for averaging. You can use addresses (199-206) You do not need to do additional steps it will average automatically.
- Each averaging sensor will display it's local temp not the average. While looking at the SBH for that SA bus it will display the average. If you want to see the individual averaging sensor temp click on the **controller>details>netsensor plug and play**.
- This is a 4 wire bus & will not work on 3 wires. Use 18awg to 22awg
- In a retrofit application existing stat wire maybe used as long as you have 4 conductors
- If you are using a sensor with CO2 it's lifespan is 10 years under standard operating conditions
- If you are using a sensor with PIR it can work up to 26ft with clear line of site
- You can add a MAP tool on the bottom of the sensor to access the devices on the bus
- You have the option to terminate to the sensor with a modular jack or screw terminals



Dipswitch Settings							
OFF → ON	OFF → ON	OFF → ON	OFF → ON	OFF → ON	OFF → ON	OFF → ON	OFF → ON
199	200	201	202	203	204	205	206

Tech Tip: In order for an NS8000 sensor to work properly you need to be running 4.1 firmware or newer.

Drawing Title							
Sensor Detail							
Project Title							
3rd Party COBP							
REFERENCE DRAWING		NO.	REVISION-LOCATION	ECN	DATE	BY	
Sales Engineer	Project Manager	Application Engineer	Steve Nichols	DATE 12-30-2021	BY	DATE	
VERASYS		CONTRACT NUMBER		DRAWING NUMBER			
				12			

NS8000 Color Sensor Detail

	Up Arrow-Cannot Hide Icon
	Down Arrow-Cannot Hide Icon
	Background Light-Cannot Hide Icon
	Background Dark-Cannot Hide Icon
	Brightness Bar-Cannot Hide Icon
	Brightness-Cannot Hide Icon
	Cancel-Cannot Hide Icon
	Checkmark-Cannot Hide Icon
	Fan Speed-Can Hide Icon
	Fan Auto-Can Hide Icon
	Fan Speed Bars-Can Hide Icon
	Relative Humidity-Can Hide Icon
	CO2-Can Hide Icon
	Occupancy-Can Hide Icon
	Setpoint-Can Hide Icon
	Occupancy-Cannot Hide Icon
	Setpoint-Cannot Hide Icon
	Settings-Can Hide Icon
	Settings Lock-Can Hide Icon
	Temperature-Cannot Hide Icon
	Settings Enabled-Cannot Hide Icon
	Settings Disabled-Cannot Hide Icon
	Error-Cannot Hide Icon
	Page Indicator-Cannot Hide Icon
	Scroll Arrows-Cannot Hide Icon
	Timeout-Cannot Hide Icon
	Screen Dim-Cannot Hide Icon
	Screen Off-Cannot Hide Icon



- Once you connect the NS to a controller that is connected to a SBH it will hold it's parameters when there's a power cycle

-To change the address hold the network icon for 3 seconds, then hold the "SA Bus" for 3 seconds then use the arrow & save

- If the sensor is the only one on the bus there is no need to change the default address

-You can have a max of 8 NS sensors on the sensor bus that can be daisy chained for averaging. You can use addresses (199-206)
You do not need to do additional steps it will average automatically.

-Each averaging sensor will display it's local temp not the average. While looking at the SBH for that SA bus it will display the average. If you want to see the individual averaging sensor temp click on the **controller>details>netsensor plug and play.**

-This is a 4 wire bus & will not work on 3 wires. Use 18awg to 22awg

- In a retrofit application existing stat wire maybe used as long as you have 4 conductors

- If you are using a sensor with CO2 it's lifespan is 10 years under standard operating conditions

- If you are using a sensor with PIR it can work up to 26ft with clear line of site

- You can add a MAP tool on the bottom of the sensor to access the devices on the bus


- You have the option to terminate to the sensor with a modular jack or screw terminals

-To change the set point range log into the **Smart Building Hub, Devices**, click on the controller your stat is attached to & go to **Setpoints**,

-To lock out the color screen see the installation guide in the link below

-To hide icons on the color display refer to the installation guide in the link below

<https://docs.johnsoncontrols.com/bas/r/Johnson-Controls/en-US/Vertical-Wallbox-Mounted-or-Surface-Mounted-NS8000-Series-Network-Sensors-Graphical-Display-Models-Installation-Guide/D>



Locate sensor away from steam, water pipes, warm air stacks, unconditioned areas (not heated or cooled), sources of electrical interference, or on walls that radiate the temperature from the outside (you can use a thermal barrier)

Make sure to plug conduit coming from an unconditioned space to keep cold or warm air from being pushed down conduit to the back of the sensor

Height requirements may vary depending on the site & ADA requirements

Network sensors without CO2 sensing are shock & vibration resistant, but not shock & vibration proof. Be careful not to drop the unit or mount it where it could be exposed to excessive vibration. Dropping CO2 network sensor may result in reading outside of the specified accuracy tolerance


Display Text	Economizer Fault Condition	Possible Problem
E0	Air Temp Sensor Failure or Fault	Problem with one of the air temperature sensors. Check outdoor air, return air, or supply air sensors
E1	Not economizing when it should	The economizer is not using outdoor air when it should
E2	Economizing when it should not	The economizer is allowing outdoor air inside when the conditions are not suitable for economizer operation
E3	Damper not modulating	The economizer damper is not able to modulate properly, Check damper, linkage to actuator, or the actuator
E4	Excess outdoor air	The economizer is allowing excess air inside



Tech Tip:

In order for an NS8000 C02 sensor to work properly your SSE card needs to be running 4.0.1 firmware or higher. SSE cards with 4mb or 3.0 firmware will not work with 4.0.1 firmware. An SSE card needs at least 8mb to run the 4.0.1 firmware & pretty much any SSE card made before 2017 only has 4mb of memory.




Drawing Title									
	REFERENCE DRAWING		NO.	REVISION-LOCATION		ECN	DATE	BY	
Sales Engineer		Project Manager	Application Engineer	DRAWN		APPROVED			
				BY	SJN	DATE	6-20-2022	BY	DATE
Project Title SMART RTU				Branch Information			CONTRACT NUMBER		
							DRAWING NUMBER		
							12		

Damper Wiring Detail


OUTSIDE AIR DAMPER






Tech Tip:

An M9208-250 Mounting Bracket Kit may be needed for this application. Verify existing damper needs & order as needed.



MIXED AIR DAMPER






120vac

Tech Tips:



Make sure the 2nd actuator is set to reverse 0-10

It's also mandatory that the 2nd actuator connects to the damper position of the previous actuator.




Drawing Title							
Actuator Detail							
REFERENCE DRAWING		NO.	REVISION-LOCATION		ECN	DATE	BY
Sales Engineer	Project Manager	Application Engineer	By Steve Nichols	DATE 12-30-2021	BY	DATE	
Project Title		3rd Party COBP		VERASYS		CONTRACT NUMBER	
						DRAWING NUMBER	
						13	

Dip Switch Addresses



Tech Tip: If you change a dipswitch while the ZEC is powered you will need to do a power cycle for it to change.



#4
ON
OFF
128 64 32 16 8 4 2 1

#5
ON
OFF
128 64 32 16 8 4 2 1

#6
ON
OFF
128 64 32 16 8 4 2 1

#7
ON
OFF
128 64 32 16 8 4 2 1

#8
ON
OFF
128 64 32 16 8 4 2 1

#9
ON
OFF
128 64 32 16 8 4 2 1

#10
ON
OFF
128 64 32 16 8 4 2 1

#11
ON
OFF
128 64 32 16 8 4 2 1

#12
ON
OFF
128 64 32 16 8 4 2 1

#13
ON
OFF
128 64 32 16 8 4 2 1

#14
ON
OFF
128 64 32 16 8 4 2 1

#15
ON
OFF
128 64 32 16 8 4 2 1

#16
ON
OFF
128 64 32 16 8 4 2 1

#17
ON
OFF
128 64 32 16 8 4 2 1

#18
ON
OFF
128 64 32 16 8 4 2 1

#19
ON
OFF
128 64 32 16 8 4 2 1

#20
ON
OFF
128 64 32 16 8 4 2 1

#21
ON
OFF
128 64 32 16 8 4 2 1

#22
ON
OFF
128 64 32 16 8 4 2 1

#23
ON
OFF
128 64 32 16 8 4 2 1

#24
ON
OFF
128 64 32 16 8 4 2 1

#25
ON
OFF
128 64 32 16 8 4 2 1

#26
ON
OFF
128 64 32 16 8 4 2 1

#27
ON
OFF
128 64 32 16 8 4 2 1

#28
ON
OFF
128 64 32 16 8 4 2 1

#29
ON
OFF
128 64 32 16 8 4 2 1

#30
ON
OFF
128 64 32 16 8 4 2 1

#31
ON
OFF
128 64 32 16 8 4 2 1

#32
ON
OFF
128 64 32 16 8 4 2 1

#33
ON
OFF
128 64 32 16 8 4 2 1

#34
ON
OFF
128 64 32 16 8 4 2 1

#35
ON
OFF
128 64 32 16 8 4 2 1

#36
ON
OFF
128 64 32 16 8 4 2 1

#4
OFF
ON
128 64 32 16 8 4 2 1

#5
OFF
ON
128 64 32 16 8 4 2 1

#6
OFF
ON
128 64 32 16 8 4 2 1

#7
OFF
ON
128 64 32 16 8 4 2 1

#8
OFF
ON
128 64 32 16 8 4 2 1

#9
OFF
ON
128 64 32 16 8 4 2 1

#10
OFF
ON
128 64 32 16 8 4 2 1


#11
OFF
ON
128 64 32 16 8 4 2 1

#12
OFF
ON
128 64 32 16 8 4 2 1

#13
OFF
ON
128 64 32 16 8 4 2 1

Drawing Title									
Addressing Detail									
Project Title		3rd Party COBP		VERASYS		CONTRACT NUMBER		DRAWING NUMBER	
								14	

RIB PSH300 Detail




Tech Tip:



High voltage wire & comm wire should never be in the same conduit or zipped tied together

Drawing Title							
Power Supply Detail							
REFERENCE DRAWING		NO.	REVISION-LOCATION		ECN	DATE	BY
Sales Engineer	Project Manager	Application Engineer	Steve Nichols	DATE	7-11-2022	BY	DATE
Project Title		Branch Information		CONTRACT NUMBER			
3rd Party COBP		VERASYS™		DRAWING NUMBER			
				15			

Verasys Enclosure



Drawing Title Enclosure							
REFERENCE DRAWING		NO.	REVISION-LOCATION		ECN	DATE	BY
Sales Engineer	Project Manager	Application Engineer	Steve Nichols	DATE 7-7-2022	BY	DATE	
Project Title 3rd Part COBP		VERASYS™		CONTRACT NUMBER		DRAWING NUMBER 16	

Verasys Enclosure



Tech Tip: High voltage wire & comm wire should never be in the same conduit or zipped tied together

120vac
Installed by electrician

Installed By HVAC
Contractor



24v

Zone Bus

HVAC Contractor
works with I.T.
Group


1) Network
cable

RIB PSH300 #1



RIB PSH300 #2

HVAC Contractor provides panel enclosure





Tech Tip: Install SBH & connect to internet before job starts. See page 13-16

VZC RTU 1



VZC RTU 2







Tech Tip: A PSH300A can power 18 devices.

Drawing Title									
Enclosure									
Project Title		3rd Part COBP		VERASYS		16			
REFERENCE DRAWING		NO.		REVISION-LOCATION		ECN		DATE	
Sales Engineer		Project Manager		Application Engineer		BY Steve Nichols		DATE 7-7-2022	
Branch Information		CONTRACT NUMBER		DRAWING NUMBER					

Verasys Enclosure



Tech Tip:  Install SBH & connect to internet before job starts. See pages 12 & 13

Tech Tip:  High voltage wire & comm wire should never be in the same conduit or zipped tied together


Tech Tip:  An SBH can talk to 100 controllers or 10 VZCs. Each VZC counts as 10 controllers. If you have 7 VZCs you are using 70 controllers & have 30 controller spaces left.

Tech Tip:  Each VZC can talk to 32 zone controllers.


Tech Tip:  A PSH300A can power 18 devices.

Drawing Title									
Enclosure									
REFERENCE DRAWING		NO.		REVISION-LOCATION		ECN		DATE	
Sales Engineer		Project Manager		Application Engineer		DRAWN		APPROVED	
Project Title		3rd Party COBP		By Steve Nichols		DATE 8-30-2022		BY	
								CONTRACT NUMBER	
								DRAWING NUMBER	
								16	


Verasys Enclosure



Tech Tip:  High voltage wire & comm wire should never be in the same conduit or zipped tied together

Tech Tip:  Install SBH & connect to internet before job starts. See page 8-11

Tech Tip:  A PSH100A can power 6 devices.

Drawing Title						
Enclosure						
REFERENCE DRAWING		NO.	REVISION-LOCATION		ECN	DATE
Sales Engineer	Project Manager	Application Engineer	By Steve Nichols	DATE 7-7-2022	BY	DATE
Project Title		Branch Information		CONTRACT NUMBER		
3rd Part COBP				DRAWING NUMBER		
				16		

Standard Installation Procedures

- Step 1: At your office pull out all the controllers & wire them up to the SBH referring to pages 3 & 4. (do not apply power yet)
- Step 2: Address the VZC, BYPs, ZECs according to Page 3 Riser Diagram & label each.
- Step 3: Power up & log into your SBH & verify firmware & update if needed. (watch YouTube video)
- Step 4: Power up VZC & verify it shows up in the SBH device list with the proper address.(watch YouTube video)
- Step 5: Power up the VEC, change the address if needed.
- Step 6: Log into the VEC & configure it for COBP. “Details” \ “Service” \ “Factory” \ “Rooftop Controller Type”=Changeover Bypass
- Step 7: Power up BYP200 & verify it shows up under the VZC on the SBH. (watch YouTube video)
- Step 8: Power up each ZEC310 & Verify they show up under the VZC.
- Step 9: Back on the SBH give each controller a descriptor. (Write a descriptor as if you showed up on job after the install & don’t know where anything is)
- Step 10: Log into each ZEC 310 & configure as needed giving each a vote (0-4)(watch YouTube video)
- Step 11: Create a schedule for your VZC. (Each VZC is capable of having 4 schedules)----->
- Step 12: Attach 1 of the 4 schedules to each ZEC310.
- Step 13: Verify the firmware is current on the VZC & update if needed. (When you update the VZC it will also update all the controllers on the Zone Bus)
- Step 14: If you have a 2nd VZC repeat steps 2-13.
- Step 15: At the jobsite Install PSH100 power supply. See page 3. Have licensed Electrician terminate high voltage to power supply.
- Step 16: Install SBH & apply power to it from PSH100. Get SBH connected to internet. See pages 8-11.
- Step 17: Install VZC next to SBH, terminate BACnet bus from VZC to SBH, power up VZC, & verify it shows up on SBH. See page 4.
- Step 18: Pull BACNet wire from VZC to all the controllers (strip but don’t terminate wires yet). See pages 3 & 4.
- Step 19: While pulling the BACnet wire pull a 2 conductor 16awg power bus to all controllers. See page 3 Riser Diagram.
- Step 20: Check all wires you just pulled for ground faults before you apply power or terminate BACnet bus.
- Step 21: Install VEC controller inside RTU (leave powered down)
- Step 22: Install DA, RA, & OA sensors & terminate to VEC checking all wires for ground faults. See page 5.
- Step 23: Terminate all outputs on the VEC checking all wires for ground faults. See page 5.
- Step 24: Power up VEC & verify it shows up on the SBH under the VZC.
- Step 25: Install the BYP200 on the bypass damper & terminate BACnet wire checking for ground faults first.
- Step 26: Install Discharge Air Static Pressure Sensor & terminate to BYP200. See page 7.
- Step 27: If you have a 2nd Bypass Damper install actuator following wiring on page 7.
- Step 28: Apply power to the BYP & verify it shows up on the SBH under the VZC.
- Step 29: Install ZEC310s on each of the zone dampers & terminate BACnet wires. See page 6.
- Step 30: Unless there’s existing stat wire from controller to wall\zone sensor pull a 4 conductor wire. See pages 3 & 6.
- Step 31: On SA bus wires check for ground faults. Terminate the SA bus to controller & wall module. See page 3 & 6.
- Step 32: Power up first ZEC310 controller & verify it shows up on the SBH. Repeat step 32 until all ZECs are showing up on SBH.
- Step 33: Test your VEC. On the SBH click on “Devices”, select your VZC then VEC \ “Commissioning” \ “Commission Output” \ “Start Commissioning” \ set to “Trigger” \ now test each option verifying functionality.
- Step 34: Go Back to “Start Commissioning” & set to “Normal”.
- Step 35: Test each ZEC310. On the SBH click on “Devices”, select your VZC then VEC “Commissioning” & test functionality.
- Step 36: Cause a trouble condition & verify email & text alerts are sent.
- Step 37: Add login info (IP Address, User, & Password) to these drawings on Page 10.
- Step 38: Redline these drawings & then print a new set to leave at the SBH & email a copy to end user.

On the VZC select \ Set Schedule

Edit Zone Group 1,2,3,& 4 Schedules however you want

On the ZEC510 select \ Control Setup

select a group

ZONE GROUP NUMBER

1

PDF YouTube Links

SBH

ZEC310


VEC

BYP

VZC

Drawing Title									
Standard Installation Details									
	REFERENCE DRAWING		NO.		REVISION-LOCATION		ECN	DATE	BY
	Sales Engineer	Project Manager	Application Engineer		DRAWN		APPROVED		
					BY	DATE	7-11-2022	BY	DATE
Project Title					Branch Information		CONTRACT NUMBER		
3rd Party COBP									
							DRAWING NUMBER		
							17		

COBP Layout



Drawing Title							
COBP Layout							
Project Title							
3rd Party COBP							
REFERENCE DRAWING		NO.	REVISION-LOCATION		ECN	DATE	BY
Sales Engineer	Project Manager	Application Engineer	Steve Nichols	DRAWN	DATE	12-30-2021	BY
Branch Information		CONTRACT NUMBER		DRAWING NUMBER			
				18			

Definitions:


Actuator-A controlled piece of hardware that rotates to open & close valves or dampers
AHU-Air Handling Unit. Typically heat supplied by a boiler & cool water supplied by a chiller
BACnet IP-BACnet communication over the internet
BACnet MS\TP-Master-Slave/Token Passing. 3 wire communication bus
BACnet-A data communication protocol for building automation & control networks
BAS-Building Automation System.
BBMD-BACnet/IP Broadcast Management Device. Not used unless your using BACnet/IP
BYP200-Bypass Damper Controller used for COBP.
CO2-Carbon Dioxide. Our bodies breathe in Oxygen & breath out CO2.
COBP-Change Over Bypass may also be called VVT. A type of zoning for your building using a bypass damper & zone dampers. Each zone gets a vote & the VZC determines the order of attention for each zone.
DHCP-When a router or gateway assigns an address to each device plugged into it (Can change with power cycle)
Differential Pressure-The difference in pressure between 2 given points. (like a VAV box or a filter)
DNS-Domain Name System. Similar to a phone book for the internet.
DVC or DCV-Demand Ventilation Control. A method to add fresh air in a room using CO2 sensors.
ECM-Electronically Commutated Controller. A DC powered motor that can vary the speed & torque.
Ethernet-A system for connecting a number of computers or controllers to form a local area network.
FC-BACnet ms\tp bus. Verasys can have up to 100 devices on this bus or 10 VZCs.
Gateway-The network hardware that routes information in your building.
ISP-Internet Service Provider. (Comcast, Century Link, Cox,....)
LAN-Local Area Network. A collection of devices connected together in one physical location, such as a building, office, or home.
MA-Mixed Air. Where outside air & return air from the building mix.
OA-Outside Air. Fresh air from outside the building.
RA-Return Air. Air from the building coming back into the duct work to be reused or cycled outside.
RTU-Rooftop Unit. A packaged unit that contains heating & cooling.
SA-Sensor Bus. Verasys can have 8 devices on this bus. It has to have 4 wires. 2 for power & 2 for data.
SA-Supply Air. May also be referred to as Discharge Air. This is the conditioned air from the RTU or AHU going into the space
SBH-Smart Building Hub. The internet hub for Verasys.
SMART-A software layer on many JCI products that allows them to be a plug & play device with Verasys.
SSE-Simplicity Smart Equipment. Many York RTU\AHU\Chillers, Coleman, Lux Air, Tempmaster, Quantech Chillers have the SSE card installed. This makes them a SMART plug & play device with Verasys.
SSL-Secure Sockets Layer. A computing protocol that ensures the security of data sent via the internet by using encryption.
Static I.P. Address- Similar to a phone number but on the internet. (Fixed) Used to access the SBH.
Subnet-A method used to separate a network in a building. BAS should be on it's own Subnet.
TEC-BACnet Stat for 3rd Party RTU, Heat Pumps, Unit Heaters, & Splits. Has a built in economizer. Can't control VFDs.
TLS-Transport Layer Security. A security protocol designed to facilitate privacy and data security for communications over the Internet.
VAC-RTU Controller for 3rd Party Units. Can also be used for IOM, Lighting, Boiler, Chiller, & Sideloop applications.
VAV-Variable Air Volume. A type of zoning for your building using VAV boxes & a VFD. RTU is usually cooling only.
VEC-RTU Controller for Zoning. There are multiple apps you can install on the VEC. (Heat Pump, Mod Heat Mod Cool, Mod Heat Stage Cool, Stage Heat Mod Cool, Stage Heat Stage Cool)
VFD-Variable Frequency Drive. Hardware that allows you to vary the speed of a fan or pump. Great for saving energy!
VPN-Virtual Private Network. A layer of internet security end user typically use requiring you to have a login to access their network.
VZC-Verasys Zone Coordinator. Verasys can have up to 10 VZCs on the FC System bus.
ZA-Zone Bus. Verasys can have up 33 controllers on this bus. 32 zones & 1 controller for RTU.
ZEC310-Damper Controller used for COBP.
ZEC510-VAV Box Controller. Can be used as stand alone zone control.

The Gotchas:

- #1-Current firmware is loaded at the factory. However we don't know how long a part will sit before installation. On every job **update all hardware to current firmware versions.**
- #2-Identify what kind of system this is? SMART, 3rd Party, CV, VAV, VVT, Boiler, Chiller, Lighting, Power Monitoring? This will determine what parts & apps you need.
- #2-Is the RTU or AHU motor an ECM? (variable speed motor...no need for a VFD)
- #3-Is the fan motor single phase? (VFDs typically don't work on single phase)
- #4-Does the OA Damper have an existing actuator & if so can you re-use it?
- #5-Does the existing actuator even work?
- #6-How does the actuator mount & will we need mounting hardware to mount a new actuator?
- #7-How are you going to run the BACnet wire & how much do you need?
- #8-Where will everything mount in RTU or AHU?
- #9-Do the RTUs already have DCV & VFD's?
- #10-Where am I going to mount the SBH & can I get internet access?
- #11-Have you read the spec & have you reviewed the notes in the drawings?
- #12-Can the RTU or AHU be used for VAV? Does it have a VFD or differential pressure?
- #13-Is there already a BACnet Com card on the SSE board?
- #14-Does the SSE board have 8mb of memory? If not it will lock up the board if you load the Verasys firmware on it.
- #16-Make sure your power supply can handle the number of controllers you have on this job.
- Suggestion:** When bidding a job get pictures of the RTU TAG, nameplate on the fan motor, the inside of the RTU where equipment will mount, OA damper & how it mounts. If the RTU has an SSE card then take a detailed picture of the board & barcode on it to determine if it will work with Verasys. This is also a good time to meet with the I.T. group to see if you can be on their network. If they say "yes" then ask for: Static IP Address, Subnet Mask, Default Gateway, & Primary & a Secondary DNS Server. If they say "no" talk to the end user about getting internet from a local ISP. There's even a cellular option we could recommend for Vearsys.

Helpful Links:

<http://www.verasyscontrols.com/resources/training-and-education>
<http://www.verasyscontrols.com/resources/technical-literature-and-documentation#installation>

Drawing Title Appendix															
	REFERENCE DRAWING			NO.		REVISION-LOCATION			ECN		DATE		BY		
	Sales Engineer		Project Manager		Application Engineer		DRAWN			APPROVED					
							BY Steve Nichols DATE 1-3-2022			BY		DATE			
Project Title 3rd Party COBP						Branch Information					CONTRACT NUMBER				
DRAWING NUMBER 19															